


Spare Parts



Hafa®

Spring

Art: 1381220, 1381230

SCETCH NO	SPARE PART NO	SPRING DISKBÄNKSBLANDARE	SPRING KITCHEN MIXER CHROME
1	9209570	SPRING ENGREPPSHANDTAG	SPRING HANDLE
2	9209536	SPRING DEKORRING KROM	SPRING DECOR CAP UNDER HANDLE
3	9209580	SPRING FIXERINGSMUTTER FÖR INSATS	SPRING LOCK RING FOR CARTRIDGE
4	9209547	SPRING INSATS 35 MM	SPRING CARTRIDGE 35 MM
5	9209566	SPRING DUSCHMUNSTYCKE	SPRING CYLINDRICAL HAND SHOWER
6	9209578	SPRING CHROME FJÄDRANDE UTLOPPSSLANG	SPRING CHROME SPOUT
6	9209579	SPRING BLACK FJÄDRANDE UTLOPPSSLANG	SPRING BLACK SPOUT
7	9209593	SPRING BOTTENRING KROM	SPRING BASE RING CROME
8	9209546	SPRING STABILISERINGSPLATTA	SPRING TRIANGLE FIXING PLATE
9	9209554	SPRING MONTERINGSSATS	SPRING ASSEMBLING KIT
10	9209589	SPRING ANSLUTNINGSSLANG M10 RÖD	SPRING FLEX INOX M10 RED
11	9209588	SPRING ANSLUTNINGSSLANG M10 BLÅ	SPRING FLEX INOX M10 BLUE

Hafa®

Hafa
Svarvaregatan 5, Box 525
SE-301 80 Halmstad
SWEDEN

Garanti/Warranty.
Service, resevdelar/spare-parts
Sweden: Tel: +46 (0)35 15 44 75
Norway: Tel: +47 69 31 02 30
Finland: Puh: 0207 43 50 00

www.hafa.se
www.hafa.dk
www.hafabad.no
www.hafa.se
www.hafabathroom.ru
www.hafa.eu

E-mail:
service@hafa.se
service@hafabad.no